

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children and pets are present, take basic safety precautions, including the following:

KEEP OUT OF REACH OF CHILDREN!

READ ALL INSTRUCTIONS BEFORE USING.

KEEP AWAY FROM WATER!

DANGER — As with most electrical appliances, parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. Always unplug appliance immediately after using.
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into, water or any other liquid.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water.

WARNING — To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.
2. Do not pull, twist, or wrap line cord around appliance.
3. This appliance should not be used by, on, or near children or individuals with certain disabilities.
4. Use this appliance only for its intended use, as described in this manual. Do not use attachments not recommended by the manufacturer. Do not use an extension cord to operate appliance.
5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.
6. Keep the cord away from heated surfaces.
7. Never use while sleeping.
8. Never drop or insert any object into any opening.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Do not use an extension cord with this appliance.

11. This appliance is hot when in use. Do not let heated surfaces touch eyes or skin.

12. Do not place the appliance on any surface while it is operating.

13. Do not touch hot surfaces of the appliance; use handles or knobs.

14. Do not use this appliance near bathtubs, showers, toilets or any other recipient containing water.

15. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

16. Before plugging in, read the information about dual voltage contained in the “DUAL VOLTAGE” section of this manual.

17. When the appliance is used in bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.

18. For additional protection, the installation of a residual current device (RCD), having a rated residual operating current not exceeding 30mA, is advisable in the electrical circuit supplying the bathroom. Ask your electrician for advice.

SAVE THESE INSTRUCTIONS

SAFETY INSTRUCTIONS

1. They cannot be used by children aged 8 years or over and by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, if they have been given supervision or instructions regarding the use of the device in complete safety and provided, they understand the dangers involved. Children must not play with the appliance. Cleaning and maintenance by the user must not be carried out by children without supervision.
2. Children should be supervised to ensure that they do not play with the appliance.
3. Burn Hazard. Keep appliance out of reach from young children, particularly during use and cool down.
4. When the appliance is connected to the power supply, never leave it unattended.
5. Always place the appliance with the stand, if any, on a heat-resistant, stable flat surface.

OPERATING INSTRUCTIONS

This appliance is intended for professional use. Use on Alternating Current (50-60Hz) only. Standard appliances are designed to operate at 120-240V~.


DUAL VOLTAGE

This flat iron has dual voltage. It will automatically adjust to the proper voltage. Use an adapter plug (not included) with correct configuration, prior to use in outlet.

STRAIGHTENING BASICS

1. Plug the straightening iron into a standard electrical outlet (120-240V~). It is not necessary to touch the iron with your hand to judge readiness.
2. Use the +/- temperature controls to select the setting for your hair type. You can use the chart outlined as a reference. The iron will heat up very quickly.

TEMPERATURE SETTINGS



3. Section dry hair evenly, and comb each section. Position the iron on the hair as far up as you want hair to be straightened, being careful not to let the iron touch the scalp. Close the iron with the hair between the two plates and gently pull the iron down to the end of the section of hair you are straightening. Repeat this process several times, if necessary. Let the hair cool before combing.

STYLING TIPS USING STRAIGHTENER

For short, spiky looks use gel or spray and hold the sections up and away from the head while you straighten.

For smoothing and taming curly hair, or creating a stylish, smooth bob, use the straightener just on the ends, leaving the hair wavy at the roots for lift and body. For this type of effect, keep the straightener moving while following the shape of your hairstyle.

NANO TITANIUM

Your Nano Titanium straightening iron has many benefits. Titanium is an exceptional conductor of heat and is stable in ultrahigh temperatures. The titanium plating technology helps provide the ultimate heat performance for beautiful, healthy-looking hair. Titanium's light weight and smooth surface helps reduce time and fatigue and is exceptionally resistant to chemical corrosion. This Nano Titanium iron will give your hair a smooth, silky shine while eliminating frizz.

GET TO KNOW YOUR PROFESSIONAL STRAIGHTENER

Model BNT9091TXLUZ - 1¼"

NEW FLOATING PLATE SYSTEM

Ideal for controlling hair tension.



Unlock for floating plates that provide greater smoothness. Ideal for straight styling.

Lock if you want stronger pressure specifically if you are doing any treatment like Keratin.

NOTICE

THIS PRODUCT IS EQUIPPED WITH AN INSTANT HEAT CIRCUITRY. DO NOT LEAVE PRODUCT ON OR PLUGGED IN WHILE NOT IN USE. UNIT WILL BURN OUT IF POWER IS KEPT ON FOR AN EXTENDED PERIOD OF TIME. WARRANTY WILL BE VOIDED. TURN UNIT OFF AND UNPLUG WHEN NOT IN USE.

USER MAINTENANCE

Your styler is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool. Twist off cover and wipe curl chamber and cover with a soft damp cloth. Replace cover back on unit after dried. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION


NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then simply store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

WARNING: IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF, YOU'RE WRONG.

KEEP AWAY FROM WATER.




Everyone knows that electricity and water are a dangerous combination, but did you know that an electrical appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES.

WARNING: IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF, YOU'RE WRONG.

KEEP AWAY FROM WATER.



Everyone knows that electricity and water are a dangerous combination, but did you know that an electrical appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES.

ESSENTIAL TIPS FOR USAGE

To properly care for your hair and effectively utilize your BaBylissPRO Nano TitaniumXL™ straightener, adhere to these crucial tips:

Utilize the appropriate temperature setting based on your hair type and condition. Refer to the temperature chart provided and opt for the most suitable option. For bleached or highly damaged hair, it is advisable to use a lower temperature setting.

Always apply a thermal protector to your hair before using the straightener. This protective layer helps safeguard your hair strands from heat damage.

Avoid subjecting your hair to excessive heat exposure. Refrain from keeping the straightener stationary on any hair section for prolonged periods. The number of passes required over each section varies depending on factors such as hair type, temperature setting, ongoing treatments like keratin applications, and more. Ensure to glide the straightener over each hair segment only as needed. Refer to the temperature chart for guidance.

Temperature	Hair Type	For Straightening	For Keratin
		Plate Configuration: Floating	Plate Configuration: Fixed
		*Number of Passes	*Number of Passes
300°F/150°C	Fragile	3	10
330°F/165°C	Very Thin	3	10
360°F/180°C	Thin	3-5	10-15
390°F/200°C	Normal	3-5	10-15
420°F/215°C	Curly	3-5	10-15
450°F/230°C	Thick	3-5	10-15
485°F/250°C	Very Coarse Thick	3-5	10-15

*Please note that while these guidelines were based on tests conducted by professional stylists in a salon setting, individual results may vary depending on hair condition, thickness, user perception, and desired styling preferences.

©2024 BaBylissPRO

IB-24/207

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

STRAIGHTENING IRON REENGINEERED MAXIMIZING HEAT AND STYLING PERFORMANCE

Modelo BNT9091TXLUZ

Para su seguridad y para disfrutar plenamente de su aparato, siempre lea las instrucciones adjuntas cuidadosamente antes de usarlo.

©2024 BaBylissPRO

IB-24/207

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

BaBylissPRO

NANO TITANIUMXL™

Modelo BNT9091TXLUZ

©2024 BaBylissPRO

IB-24/207

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

2024/6/20 18:02

